



HANDBOOK

Reference Monitor

Upgrading Firmware



Manufacturers of audio & video
products for radio & TV broadcasters

SONIFEX

Upgrading Reference Monitor Firmware



If not already installed download and install the **SCI 2 Software** from the Sonifex Support website: <http://www.sonifex.co.uk/technical/software/sci/setup.exe>

Firmware Files can be downloaded from our website: <http://www.sonifex.co.uk/technical/software/index.shtml#refmon>

Copy the file to somewhere accessible on your PC.

Power up the Reference Monitor and connect a USB lead to the PC (you can also use a straight through RS232 cable).

Open the Sci software and the following Launcher screen will appear.

If your device is not listed, click the plus sign and your device should then appear in the listed devices with a COM Port number.

If your device still does not appear click 'Discover Devices' from the drop down menu.



Click 'File', then 'Save'.





Now close the window (shown above), then click on the device in the launcher as shown below.




You will now be looking at a window similar to the one below:



To update the firmware, click on the 'System' tab and select the 'Update Firmware' button. Browse to the Firmware File. To start the process click 'Open'.



The update Process will now begin. You will now see the following window:



Once the firmware has been updated the unit will reboot. After a few seconds SCi will reconnect and the new firmware version will be reported in the bottom of the window to confirm the update was successful.

SONIFEX

www.sonifex.co.uk

t:+44 (0)1933 650 700

f:+44 (0)1933 650 726

sales@sonifex.co.uk